
















Accessories VP-machines

○ = optional ● = standard

		VPO1	VPO2	VPE	VPS
Bars 35 mm for measuring ball inserts M2,5 or M4,0 or for Mahr inserts		○	○		
Bars 60 mm for measuring ball inserts M2,5 or M4,0 or for Mahr inserts		○	○	○	
Bars 35 mm for measuring pin inserts		○	○		
Bars 60 mm for measuring ball inserts		○	○	○	
Measuring ball inserts tungsten carbide available in 1 micron steps stepped, with M2,5 (from Ø1-7 mm) or M4 connecting thread (from Ø7 mm)		○	○	○	○
Measuring pin inserts, rocking and rotating		○	○	○	○
Stopping prisms for easier mounting of work pieces		○	○	○	
FRENCO-dial indicator with eccentric zero point		○	○	○	
Probe with „Haidenhain“-display		○	○	○	●
Setting rings and plugs		○	○	○	○
Flexible setting rings and plugs					○
Extension L-Dyn				○	○

Accessories VP-machines

○ = optional ● = standard

		VPO1	VPO2	VPE	VPS
Flexible bars 80 mm					●
Steel plate Ø250 with 3 air bearings, maintenance unit and button for compressed air					○
Stops for the steel plate on air bearings					○
Extension X2-axis					○